



## How To Measure For Blinds

### Face-Fit or Reveal?

You can choose to have your blind made to fit the inside of the recess of your window or it can hang on the outside.

### Face-Fit

This is the measurement you need to take if you want your blind to hang outside the window recess. We will make your blind exactly to these measurements.

### Reveal

This is the measurement you need to take if you want your blind to fit inside the window recess. We will make the necessary deductions for recess fit blinds to ensure adequate clearance. There's no need for you to make any adjustments.

### Simple steps for a face-fit measurement:

Follow these instructions if you want your blind to hang inside the window recess:

1. Measure the width of the recess from wall to wall in three places –top, centre and bottom. Note down the shortest measurement - this is the one we'll use.
2. Measure the drop by taking the measurement from the top of the recess to the windowsill in three places - left, centre and right. Note down the shortest measurement.

### Simple steps for a face-fit measurement:

Follow these instructions if you want your blind to hang outside the window recess:

1. Measure the exact width of where you'd like your blind to be. Note down the measurement.
2. Measure the exact drop from the top of where you want your blind to be to the bottom. Note down the measurement.